



Heat Exchanger Replacement

Model Include : NR981-OD, NR981-DVC, NR981-SV
NC1991-OD, NC1991-DVC
NR98OD(GQ-2857WX US), NR98DVC(GQ-2857WX-FFA US)
NR98SV(GQ-2857WX-F US)
NC199OD(GQ-2857WZ US), NC199DVC(GQ-2857WZ-FFA US)

This instructional manual is only intended for use by a qualified service professional or authorized Noritz Service Representative. Any unauthorized use of this manual may result in voiding the warranty.

Please contact Noritz Technical Support (866-766-7489) for additional support.

Noritz America Corporation

11160 Grace Avenue, Fountain Valley, CA 92708





Phone 866-766-7489 Fax 714-241-1196

Procedure








1. Drain the unit as shown in following procedure


Drainage using the Remote Controller

* RC-7651M


- 1** (1) Turn the power on/off button "off". 
- (2) Press the flow meter alarm set button for about two seconds until the alarm sounds. The maximum hot water temperature will flash.  (Ex. 120°F)
- (3) Press the flow meter alarm set button again. 
- (4) Press the setting button marked "u". The display will change from "oF" to "on" after the button is pushed. 


* RC-9018M


- (1)  button is "OFF".
- (2) Press the  button inside the cover, Select **Misc settings** using the  buttons. Press the  button. The "Misc settings" screen appears.
- (3) Select **Drain water** using the  buttons, and then press  button.
- (4) Select "YES" using the  buttons,



Press  button.




- 2** Close the water supply valve. 

- 3** Fully open all hot water fixtures.  Fixture

- 4** Open all drain plugs and drain the water out of the unit.


- 5** When the water is completely drained, replace all drain plugs and close the hot water fixtures.


- 6** Close the gas valve and disconnect the electrical power supplied to the unit. 


Do not touch with wet hands.


1. Drain the unit as shown in following procedure

Manual Draining

- 1** Close the gas valve. 


- 2** (1) Turn the power on/off button "On".
- (2) Turn and leave open the hot water fixtures/faucets for more than 2 minutes and close.  Hot water fixture/faucet
 * If multiple units are being used, drain two minutes for each unit.
 * An 11 Error Code may appear on the remote controller. This is not a malfunction of the unit. Do not turn Power ON/OFF Button OFF.

- 3** Close the water supply valve and disconnect the electrical power supplied to the unit.  **Do not touch with wet hands.**

- 4** Fully open all hot water fixtures/faucets.  Hot water fixture/faucet

- 5** Open all drain plugs and drain the water out of the unit.






- 6** When the water is completely drained, replace all drain plugs and close the hot water fixtures/faucets.





Drain Plugs

Each drain plug might not be visible if insulation is installed around the piping.







Heat Exchanger Replacement Procedure

| Procedure | Diagram |
|---|--|
| <p>2. Remove Front Cover</p> <p>(1) Disconnect electrical power to the unit (2) Turn off gas and water (3) Remove 4 screws</p> |  <p>Ex.) OD model</p> |
| <p>3. Remove Lightning Protection</p> <p>(1) DVC model for residential only ; Remove 2 screws that hold Mounting plate for Remote Controller, and unplug Remote Controller</p> <p>(2) Let Remote Controller hang outside of the unit</p> <p>(3) Remove 2 screws that hold the Lightning Protection Plate (Whichever the unit is in case No.2, 3, 4)</p> <p>(4) Let Lightning Protection hang outside of the unit</p>  <p>Case No.4 (DVC model for commercial)</p> |  <p>Case No.1 (DVC model for residential)</p>  <p>Case No.2 (OD model)</p>  <p>Case No.3 (SV model)</p> |



Heat Exchanger Replacement Procedure

| Procedure | Diagram |
|---|--|
| <p>4. Unplug all wires that attach to the wiring harness and the body of the water heater</p> <p>(1) Loosen the wire anchor from left side of the case, unplug Freeze Prevention Heater</p> <p>(2) Unplug Thermistor - Heat Exchanger</p> <p>(3) Remove Cable Tie, unplug Wiring for Remote Controller</p> <p>(4) Unplug Freeze Prevention Heaters (4), Water Servo - Main, - Bypass, and Thermistor - Hot Water</p> <p>(5) OD model only ; Unplug wiring for Power supply cord</p> <p>(6) Remove Cable Tie, unplug Wiring for Fan Motor, Water Flow Sensor, Thermistor - Cold Water, -Air Inlet and Wiring for Manifold Plate</p> | <p>Diagram</p>  <p>The diagram shows a vertical view of the internal wiring compartment. Callout (1) points to a green electrical connector on the left side. Callout (2) points to a blue electrical connector on the right side. Both connectors are circled in black.</p> |
| |  <p>This diagram provides a close-up view of the wiring harness. Callout (3) points to a black cable tie. Callout (4) points to a bundle of wires. Callout (5) points to a yellow connector. Callout (6) points to a white connector. Two boxes labeled 'Cable Tie' have arrows pointing to the locations of the cable ties.</p> |




Heat Exchanger Replacement Procedure

| Procedure | Diagram |
|--|--|
| <p>(7) Unplug wiring for Igniter</p> <p>(8) Loosen the wire anchor from right side of the case, unplug High Limit Switch, SV, DVC model only ; Unplug Freeze Prevention Heater (2)</p> <p>(9) Unplug Thermistor-Scale Detection*</p> <div style="border: 1px dashed black; padding: 5px; margin: 10px 0;"> <p>*The following models have "Thermistor - Scale Detection"</p> <p>NR98OD(GQ-2857WX US)</p> <p>NR98DVC(GQ-2857WX-FFA US)</p> <p>NR98SV(GQ-2857WX-F US)</p> <p>NC199OD(GQ-2857WZ US)</p> <p>NC199DVC(GQ-2857WZ-FFA US)</p> </div> <p style="text-align: center; margin: 10px 0;"> Thermistor - Scale Detection </p> <p>(10) Unplug Thermal Fuse (2)</p> <p>(11) Unplug Flame Rod and Ignition Plug</p> <p>(12) Remove screw that hold Circuit Board</p> <p>(13) Let all wires and Circuit Board hang outside of the unit</p> | <div style="text-align: center; margin-bottom: 20px;">  <p>(7)</p> </div> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  <p>(9)</p> </div> <div style="text-align: center;">  <p>(8)</p> </div> </div> <div style="display: flex; justify-content: space-around; margin-top: 20px;"> <div style="text-align: center;">  <p>(11)</p> </div> <div style="text-align: center;">  <p>(12)</p> </div> </div> <div style="text-align: center; margin-top: 20px;">  <p>(13)</p> <p>Ex.) SV model</p> </div> |



Heat Exchanger Replacement Procedure

| Procedure | Diagram |
|---|--|
| <p>5. SV, DVC model only ; Remove Case Top Cover from top of the unit</p> <p>(1) Disconnect the venting from the unit</p> <p>(2) SV model only ; Remove 6 screws and remove 2 Case top Covers of the unit, Gasket - Exhaust Flue and set aside.</p> <p>(3) DVC model only ; Remove 2 screws and remove Case Top Cover of the unit and set aside.</p> |  <p>(2) → → ← ← ← ←</p> <p>SV model</p> <p>SV model</p> <p>← → (2)</p> <p>DVC model</p> <p>↓ ↓ (3)</p> <p>Gasket - Exhaust Flue</p> |
| <p>6. DVC model only ; Remove Tube - Metal Back Pressure Tube</p> <p>(1) Remove 1 screw on Exhaust box that attach the tube</p> <p>(2) Remove the tube from Exhaust box</p> |  <p>←</p> <p>DVC model</p> <p>←</p> |







Heat Exchanger Replacement Procedure

| Procedure | Diagram |
|--|--|
| <p>7. Remove Manifold Plate</p> <p>(1) Remove 4 big silver screws on Manifold Plate that attach the Manifold Plate to Burner</p> <p>(2) Remove "C" Clamp</p> <p>(3) Locate inlet pipe to Manifold Plate and push up, remove the Manifold Plate</p> |  |
| <p>8. Remove Water Servo - Bypass</p> <p>(1) Remove 2 "C" Clamp</p> <p>(2) Remove Water Servo - Bypass</p> |  |
| <p>9. Disconnect a pipe from Water Flow Sensor</p> <p>(1) Remove "C" Clamp, disconnect a pipe from Water Flow Sensor</p> |  |


Heat Exchanger Replacement Procedure

| Procedure | Diagram |
|--|---|
| <p>10. Disconnect a pipe from Water Servo - Main</p> <p>(1) Remove "C" Clamp, disconnect a pipe from Water Servo - Main</p> |  |
| <p>11. Remove the assembly from Case</p> <p>(1) Remove 2 set screws on the bottom of Burner</p> <p>(2) Remove 2 set screws near the top of the case DVC model only ; Remove 4 set screws near the top of the case</p> <p>(3) Exhaust Box, Copper Heat Exchanger (CU HE), Burner, and Fan Motor will come out in one section, remove from the unit</p> |  |



Heat Exchanger Replacement Procedure

| Procedure | Diagram |
|---|--|
| <p>12. Replacing the gasket</p> <p>(1) OD model only ; Remove Gasket on the front of Exhaust Box, and reinstall Gasket onto new Exhaust Box</p> |  <p>Gasket</p> |
| <p>13. Remove CU HE</p> <p>(1) Remove 12 screws holding Burner to CU HE</p> <p>(2) Separate Burner from CU HE</p> |  <p>(1)</p> |
| <p>14. Remove the heat exchanger components from old heat exchanger and put on new heat exchanger</p> <p>(1) Front side: Freeze Prevention Heater, and Thermistor - Heat Exchanger</p> <p>(2) Right side: High Limit Switch SV, DVC model only ; Freeze Prevention Heater (Secure to put Freeze Prevention Heater on same position)</p> <div style="border: 1px solid black; padding: 5px;"> <p>Wiring Harness of Thermistor - Scale Detection The following models have "Thermistor - Scale Detection"</p> <p>NR98OD(GQ-2857WX US) NR98DVC(GQ-2857WX-FFA US) NR98SV(GQ-2857WX-F US) NC199OD(GQ-2857WZ US) NC199DVC(GQ-2857WZ-FFA US)</p> </div> | <p>(1)Front side</p>  <p>(2)Right side</p>  |
| <p>(3) Back side: Thermistor - Scale Detection*</p> <p>Remove Packing on CU HE</p> <p>Remove the small screw(M3×6) on CU HE that holding Thermistor-Scale Detection</p> <div style="border: 1px dashed black; padding: 5px;"> <p>*The following models have "Thermistor - Scale Detection"</p> <p>NR98OD(GQ-2857WX US) NR98DVC(GQ-2857WX-FFA US) NR98SV(GQ-2857WX-F US) NC199OD(GQ-2857WZ US) NC199DVC(GQ-2857WZ-FFA US)</p> </div> | <p>(3)Back side</p>  <div style="border: 1px solid black; padding: 5px; margin: 5px;"> <p>Packing - for holding Thermistor</p> </div> <div style="border: 1px solid black; padding: 5px; margin: 5px;"> <p>Thermistor - Scale Detection</p> </div> |
| <p>(4) Under side: Freeze Prevention Heater on water outlet pipe, and Freeze Prevention Heater on water inlet pipe (Secure to put Freeze Prevention Heater on same position)</p> | <p>(4)Under side</p>  |





Heat Exchanger Replacement Procedure







Heat Exchanger Replacement Procedure

| Procedure | Diagram |
|---|---|
| <p>15. Replace Gasket</p> <p>(1) Remove old burner Gasket and replace with new one</p> |  <p>Diagram (1) shows a rectangular metal burner assembly with a mesh screen inside. An arrow points to the top edge of the burner, indicating the location of the gasket to be replaced.</p> |
| <p>16. Place new O - Rings on new CU HE</p> <p>(1) Inlet to CU HE</p> <p>(2) Outlet from CU HE</p> <p>(3) Bypass from CU HE</p> |  <p>Diagrams (1), (2), and (3) show the process of placing new O-rings on the new CU HE. Diagram (1) shows the inlet to the CU HE with an arrow pointing to the O-ring location. Diagram (2) shows the outlet from the CU HE with an arrow pointing to the O-ring location. Diagram (3) shows the bypass from the CU HE with an arrow pointing to the O-ring location.</p> |




Heat Exchanger Replacement Procedure

| Procedure | Diagram |
|--|--|
| <p>17. Replace Burner, and CU HE</p> <p>(1) Attach 12 screws around perimeter of Burner and CU HE</p> |  |
| <p>18. Replace the assembly back inside the case</p> <p>(1) Secure 2 set screws near the top of the case DVC model only ; Secure 4 set screws near the top of the case</p> <p>(2) Secure 2 set screws on the bottom of Burner</p> |  <p style="text-align: center;">SV model</p>  <p style="text-align: center;">DVC model</p>  <p style="text-align: center;">(2)</p> |



Heat Exchanger Replacement Procedure

| Procedure | Diagram |
|---|---|
| <p>19. Replace Case Top Cover on top of the unit</p> <p>DVC model only ; (1) Attach Case Top Cover to the unit and secure 2 screws</p> <p>SV model only ; (1) Attach Big Case Top Cover to the unit and secure 4 screws (2) Place Gasket - Exhaust Flue on Exhaust pipe (3) Attach Small Case Top Cover to the unit and secure 2 screws (4) Reconnect the venting to the unit</p> |  <p>DVC model</p>  <p>SV model</p>  <p>(2)</p>  <p>(3)</p> |

Heat Exchanger Replacement Procedure

| Procedure | Diagram |
|--|--|
| <p>20. Reconnect a pipe to Water Servo - Main</p> <p>(1) Insert a pipe to Water Servo - Main, and attach "C" Clamp</p> |  |
| <p>21. Reconnect two pipes to Water Servo - Bypass</p> <p>(1) Replace Water Servo - Bypass</p> <p>(2) Attach 2 "C" Clamp</p> |  |
| <p>22. Reconnect a pipe to Water Flow Sensor</p> <p>(1) Insert a pipe to Water Flow Sensor, and attach "C" Clamp</p> |  |

Heat Exchanger Replacement Procedure





| Procedure | Diagram |
|--|--|
| <p>23. Replace Manifold Plate</p> <p>(1) Secure the Manifold Plate to Burner with 4 big silver screws</p> <p>(2) Secure gas pipe of Manifold Plate to gas inlet fitting with "C" Clamp</p> |  |
| <p>24. Replace Tube - Metal Back Pressure Tube</p> <p>DVC model only ;</p> <p>(1) Attach Tube with 1 screw.</p> |  |

Heat Exchanger Replacement Procedure







| Procedure | Diagram |
|--|---------|
| <p>25. Reconnect all wires that attach to the wiring harness and the body of the unit</p> <p>(1) Insert Circuit Board and attach with screw</p> <p>(2) Plug Flame Rod and Ignition Plug</p> <p>(3) Plug wiring for Igniter</p> <p>(4) Plug High Limit Switch SV, DVC model only ; Plug Freeze Prevention Heater (2)</p> <p>(5) Plug Thermistor - Scale Detection*</p> <div style="border: 1px dashed black; padding: 5px; margin: 10px 0;"> <p>*The following models have "Thermistor - Scale Detection"</p> <p>NR98OD(GQ-2857WX US)</p> <p>NR98DVC(GQ-2857WX-FFA US)</p> <p>NR98SV(GQ-2857WX-F US)</p> <p>NC199OD(GQ-2857WZ US)</p> <p>NC199DVC(GQ-2857WZ-FFA US)</p> </div> <p>(6) Plug Thermal Fuse (2)</p> <p>(7) Tie all wires (<u>except for Ignition Wire</u>) with the anchor from right side of the case</p> <div style="background-color: yellow; border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>Caution!</p> <p>1. Don't tie Ignition Wire with the anchor.</p> <p>2. Set Ignition wire behind of other wires.</p> </div> <div style="text-align: center; margin: 10px 0;"> <div style="border: 1px solid gray; padding: 2px 10px; display: inline-block;">Thermistor - Scale Detection</div> </div> <div style="background-color: yellow; border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>Caution!</p> <p>1. Don't tie Ignition Wire with the anchor.</p> <p>2. Set the Ignition wire behind of other wires.</p> </div> | |

Heat Exchanger Replacement Procedure

| Procedure | Diagram |
|---|--|
| <p>(6) Plug Freeze Prevention Heater Tie the wire anchor from left side of Case DVC model only ; Don't tie the Tube with the anchor</p> <p>(7) Plug Themistor - Heat Exchanger</p> <p>(8) Plug Wiring for Remote Controller, tie Cable Tie</p> <p>(9) Plug Freeze Prevention Heaters (4), Water Servo - Main, - Bypass, and Thermistor - Hot Water</p> | <p>Diagram</p> <p>Caution! Don't tie the Tube with the anchor.</p> |
| <p>(10) OD model only ; Plug wiring for Power supply cord (Yellow connector)</p> | |
| <p>(11) Plug Wiring for Fan Motor, Water Flow Sensor, Thermistor - Cold Water, -Air Inlet and Wiring for Manifold Plate, And then tie wirings with Cable Tie</p> | |
| | |
| <p>*NR98OD/SV/DVC(GQ-2857WX * *) and NC199OD/DVC(GQ-2857WZ * *) have "Blue connector" for Scale Flushing</p> <p>NOTE ; Don't connect this blue connector when replacing Heat Exchanger</p> | |

| Procedure | Diagram |
|--|--|
| <p>26. Replace Lightning Protection</p> <p>(1) DVC model for residential only ; replace Remote Controller, plug Remote Controller, and attach the Mounting plate for Remote Controller with screw</p> <p>(2) Attach Lightning Protection Plate with 2 screws (Whichever the unit is in case No.2, 3, 4)</p> |  <p>Case No.1 (DVC model for residential)</p>  <p>Case No.2 (OD model)</p>  <p>Case No.3 (SV model)</p>  <p>Case No.4 (DVC model for commercial)</p> |

Heat Exchanger Replacement Procedure

| Procedure | Diagram |
|---|---|
| <p>27. Check for water leak</p> <ol style="list-style-type: none"> (1) Secure 3 drain valves (2) Turn on water inlet valve slowly (check for leaks around "C" Clamps) (3) If you get leaks, close water inlet valve Re-secure "C" Clamps of leaking points |  |
| <p>28. Check for gas leaks and doing trial operation</p> <ol style="list-style-type: none"> (1) Turn on gas supply valve (2) Turn on the unit Check for leaks around Manifold Plate and joining areas For example ; Between Burner and CU HE (3) If you get leaks, Close gas supply valve Re-secure "C" Clamps of leaking points | |
| <p>29. Replace Front Cover</p> <ol style="list-style-type: none"> (1) Secure Front Cover with 4 screws |  <p>Ex.) OD model</p> |
| <p>30. Check for correct operation of the water heater. The following steps are for "NR98OD/DVC/SV(GQ-2857WX**)" and "NC199OD/DVC(GQ-2857WZ**)"</p> <ol style="list-style-type: none"> (1) Turn on the remote controller The water heater does not need to run now (Do not open the water outlet valve and faucet) (2) Press and hold both the "UP(▲)" and "DOWN(▼)" buttons simultaneously for more than 2 seconds to enter the Maintenance Monitor mode* "03" will first appear on the remote controller *The maintenance monitor data No. will appear on the display for 2 seconds, and then the data will appear (Type A remote controller only) (3) Push the "UP(▲)" button until you see the data No.35** **The data No.35 shows the "Temperature of Thermistor-Scale Detection" (4) Turn on the gas supply valve, and then open the water supply valve and faucet (water outlet valve) to run the water heater for at least 1 minute. (5) Check whether the data No.35 rises when the water heater is running (The water heater operation is correct if it displays more than 32°F) If the temperature does not rise or displays 32°F, then the connection to the Thermistor-Scale Detection need to be checked and repeat (1) - (5) in step 30 (6) Press and hold both the "UP(▲)" and "DOWN(▼)" buttons simultaneously for more than 2 seconds to return normal mode | <div style="border: 1px dashed black; padding: 5px;"> <p>Type A</p>  <p>2 seconds later</p> <p>Type B</p>  <p>Ex.) This shows the data No.35 "75°F" (Thermistor-ScaleDetection detects "75°F")</p> </div> <div style="border: 1px dashed black; padding: 5px; margin-top: 10px;">   <p>Ex.) This shows the data No.35 rises "75°F" to "125°F" when the water heater is running</p> </div> |